

















AIR HOCKEY




ITEM NO.:6011.004

PARTS LIST


<p>#1</p>  <p>Main Frame 1 piece</p>	<p>#2</p>  <p>Left leg 2 pieces</p>	<p>#3</p>  <p>Right leg 2 pieces</p>	<p>#4</p>  <p>Leg end panel 2 pieces</p>
<p>#5</p>  <p>Leg long panel 1 piece</p>	<p>#6</p>  <p>Pusher 2 pieces</p>	<p>#7</p>  <p>Pusher felt sticker 2 pieces</p>	<p>#8</p>  <p>Round puck 2 pieces</p>
<p>#9</p>  <p>Slide scorer 2 pieces</p>	<p>#10</p>  <p>1/4" x 1" Bolt 12 pieces</p>	<p>#11</p>  <p>1/4" Washer 12 pieces</p>	<p>#12</p>  <p>8# x 2" Screw 4 pieces</p>
<p>#13</p>  <p>T4 x 3/4" Screw 8 pieces</p>	<p>#14</p>  <p>F4 x 1" Screw 4 pieces</p>	<p>#15</p>  <p>4mm Allen Key 1 piece</p>	

Assembly Instructions

Step 1



Step 2



Step 3

